

Manufacturer	Locomotive/Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement	Made In
Deluxe Innovations	Rolling Stock		Gunderson High-side wood chip car (10,000 series)	Deluxe Innovations	1129 (001 30 013), 1130 (001 30 014)	2001 (001 02 050)			USA
Deluxe Innovations	Rolling Stock		Twin Tub coal gondola (12,000 series)	Deluxe Innovations	1128 (001 30 012)			1035 (003 01 041)	USA
Deluxe Innovations	Rolling Stock		Shallow Rib Wood Chip Car		1023 (001 02 009), 1025			1037 (003 01 042)	
Dimi-Trains	Steam		0-8-0 Switcher (w/ tender): pilot	Rivarossi		1041 (bodymount MTL pilot with truck mounted tender conversion)			
Dimi-Trains	Steam		0-8-0 Switcher (w/ tender):(Converts to 2-8-0 Consolidation)	Rivarossi		1042 (bodymount MTL pilot with truck mounted tender conversion)			
Dimi-Trains	Steam		2-8-2 USRA Mikado (w/ 4-wheel tender truck)	Rivarossi	(tender only) 1129 (001 30 013), 1130 (001 30 014)	1043 (001 30 010) (bodymount MTL pilot with truck mounted tender conversion)			
Dimi-Trains	Steam		2-8-2 USRA Mikado (w/ 6-wheel tender truck)	Rivarossi	(tender only) 1129 (001 30 013), 1130 (001 30 014)	1043 (001 30 010)-1 (MTL Pilot and tender)			
Dimi-Trains	Diesel	EMD	SW-1500 Cow (with or without power)	Rivarossi shell & chassis		1111 (001 30 007)			
Dimi-Trains	Diesel	EMD	SW-1500 Calf (with or without power)	Rivarossi shell & chassis		1111 (001 30 007)			
Dimi-Trains	Diesel	EMD	SW-1500 Cow (with or without power)	Rivarossi shell & Kato chassis		1021 (001 02 021)/1022			
Dimi-Trains	Diesel	EMD	SW-1500 Calf (with or without power)	Rivarossi shell & Kato chassis		1021 (001 02 021)/1022			
Dimi-Trains	Rolling Stock		Brownhoist Crane					1000 (003 01 021), 1010 (001 30 004) (003 01 001)	
Dimi-Trains	Rolling Stock		Vanderbilt tender					1010 (001 30 004) (003 01 001)	
Dimi-Trains	Cars		Passenger or Freight Cars (w/ split 1 pc. draft gear box)		1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)				
Dimi-Trains	Cars		Passenger or Freight Cars (w/ metal draft gear box clip)		1104 (001 30 009) (001 30 009), 1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)				
Dimi-Trains	Cars		Freight truck (w/ mounted MTL coupler assy)					1000 (003 01 021), 1002 (003 01 024), 1003 (003 01 022), 1010 (001 30 004) (003 01 001), 1030 (003 01 031), 1012 (003 01 004), 1030 (003 01 031), 1032 (003 01 034), 1035 (003 01 041), 1037 (003 01 042), 1038 (003 01 044)	
Dimi-Trains	Cars		Passenger truck (w/ mounted MTL coupler assy)					1017 (003 41 051), 1018 (003 41 061)	
Dimi-Trains	Cars		Passenger or Freight Cars, body mount				body mount (refer to the body mount applications section in the conversion guide for instructions)		
E & C Shops	Rolling Stock		Delaware Valley Cylindrical Hoppers (See 1/96 Flier)			1023 (001 02 009)	1035 (003 01 041), 1023 (001 02 009)	1035 (003 01 041)	
E & C Shops	Rolling Stock		Johnstown Coal Porter	E & C	1128 (001 30 012), 1129 (001 30 013)	1015 (001 02 000)/1016 (001 02 006)		1035 (003 01 041)	USA
E R MODEL IMPORTERS, LTD.	Rolling Stock		Talgo Pendular			1016 (001 02 006)	Rear and Front car must be disassembled and the coupler attached to the bottom of the grey platform inside the car		
E R MODEL IMPORTERS, LTD.	Diesel		Sharks, A and B units	E R	1134 (001 33 031) on front 1133 (001 33 030) on rear				
E R MODEL IMPORTERS, LTD.	Rolling Stock		Bay Window Caboose			1049 (001 30 003)			
E R MODEL IMPORTERS, LTD.	Cars		Track Cleaning Box Car	Roco		1027 (001 02 014)		1000 (003 01 021)	Austria
Fleishman	Steam		All loco's produced at this point		1104 (001 30 009) (001 30 009)	1015 (001 02 000)			