

Manufacturer	Locomotive/Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement
Kato	Steam		BR-86 (German Prototype)	Kato	1128 (001 30 012), 1129 (001 012), 1129 (001 012), 1129 (001 012)			
Kato	Steam		BR-86 (German Prototype)	Kato	1128 (001 30 012), 1129 (001 012), 1129 (001 012)			
Kato	Steam		BR-86 (German Prototype)	Kato	1128 (001 30 012), 1129 (001 012), 1129 (001 012)			
Kato	Steam		BR-86 (German Prototype)	Kato	1128 (001 30 012), 1129 (001 012), 1129 (001 012)			
			GS4 SP Daylight Loco	Kato	1129		Tender only, no pilot conversion	
Kato	Steam		2-8-2 Mikado	Kato	1129	2002		
Kato	Steam		282 D51	Kato	1129 (001 30 013)		Tender only, no pilot conversion	
Kato	Steam		260 C50	Kato	1129 (001 30 013)		Tender only, no pilot conversion	
Kato	Steam		2-6-2 Japanese Prototype	Kato	1128 (001 30 012)		Tender only, no pilot conversion	
Kato	Diesel	Alco	PA-1 (1998 release)	Kato		2000		
Kato	Diesel	Alco	PB-1 (1998 release)	Kato	1128 (001 30 012), 1129 (001 30 013), 1130			
<b>Kato</b>	<b>Diesel</b>	<b>Alco</b>	<b>PA-1 PB-1 2004 (001 02 052) Release</b>	<b>Kato</b>	<b>1129 (001 30 013)</b>	<b>2004 (001 02 052)-1</b>	<b>Only front of PA-1 takes 2004 (001 02 052)-1, rest are 1129 (001 30 013)</b>	
<b>Kato</b>	<b>Diesel</b>	<b>Budd</b>	<b>Rail Diesel Car (RDC)</b>	<b>Kato</b>		<b>2004 (001 02 052)-1</b>	<b>Remove factory coupler and "cow catcher", center coupler and afix with 00-90 screw.</b>	
Kato	Diesel	EMD	E8 & E9 'A' Unit	Kato		2000 (bodymount pilot coupler with truck mounted rear conversion)		
Kato	Diesel	EMD	E8 & E9 'B' Unit	Kato	1128 (001 30 012)			
<b>Kato</b>	<b>Diesel</b>		<b>F7 &amp; F3 A</b>	<b>Kato</b>			<b>2000 (incl 2004 (001 02 052) Front, 1128 (001 30 012) Rear )</b>	
Kato	Diesel	EMD	F7 & F3 'A' Unit: Obsolete	Kato		1159 (bodymount pilot coupler with truck mounted rear conversion)		
Kato	Diesel	EMD	F7 & F3 'B' Unit	Kato	1128 (001 30 012)			
Kato	Diesel	EMD	GP-7	Kato for Atlas		1155 (001 32 110) (MTL pilot: front & rear; blk, gray, blue)		
Kato	Diesel	EMD	GP-9	Kato for Atlas		1155 (001 32 110) (MTL pilot: front & rear; blk, gray, blue)		
Kato	Diesel		GP-30 (New)			1015 (001 02 000), 1016 (001 000)		
Kato	Diesel	EMD	GP38/GP38-2	Kato		1151 (001 41 000) (MTL pilot: front & rear; blk, gray, blue)		

Manufacturer	Locomotive/Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement
Kato	Diesel	EMD	GP50	Kato		1157 (001 41 010) (MTL pilot: front & rear; blk, gray, blue)		
Kato	Diesel	Alco	RS-1	Kato		1158 (001 32 070) (MTL pilot: front & rear)		
Kato	Diesel	Alco	RSC-2	Kato		2004 (001 02 052)		
Kato	Diesel	Alco	RS-2	Kato		2001 (001 02 050), 2004 (001		
Kato	Diesel	Alco	RS-3	Kato		1152 (001 32 040) (MTL pilot: front & rear)		
Kato	Diesel	Alco	RS-3	Kato		2004 (001 02 052)-1	Newest release.	
Kato	Diesel	Alco	RS-11	Kato		1128 (001 30 012)		
Kato	Diesel	Alco	RSD 4/5	Kato		1153 (001 32 050) (MTL pilot: front & rear)		
Kato	Diesel	Alco	RSD 12	Kato		1154 (001 32 060) (MTL pilot: front & rear)		
Kato	Diesel	EMD	SD-7	Kato		1162 (001 32 090) (MTL pilot: front & rear; 12 colors)		
Kato	Diesel	EMD	<b>NW2</b> SD-9	<b>Kato</b> Kato for Atlas		<b>2004-1</b> 1162 (001 32 090) (MTL pilot: front & rear; 12 colors)		
<b>Kato</b>	<b>Diesel</b>	<b>EMD</b>	<b>SD-40</b>	<b>Kato</b>		<b>2001 (001 02 050)</b>		
Kato	Diesel	EMD	SD-40-2	Kato		2004 (001 02 052)	For tighter radius layouts, the 2001 (001 02 050) long shank coupler can be used	
Kato	Diesel	EMD	SD-40-2 Snoot Nose	Kato		2004 (001 02 052)	For tighter radius layouts, the 2001 (001 02 050) long shank coupler can be used	
Kato	Diesel	EMD	SD-45	Kato		1015 (001 02 000)		
<b>Kato</b>	<b>Diesel</b>	<b>EMD</b>	<b>SD-70 MAC</b>	<b>Kato</b>		<b>2003, 1015</b>	<b>Open pilot in lower corners to make fit easier</b>	
Kato	Diesel	EMD	SD-80/90	Kato		2004 (001 02 052)	For tighter radius layouts, the 2001 (001 02 050) long shank coupler can be used	
<b>Kato</b>	<b>Diesel</b>	<b>EMD</b>	<b>SD-90 mac</b>	<b>Kato</b>		<b>2004 (001 02 052)</b>	<b>For tighter radius layouts, the 2001 (001 02 050) long shank coupler can be used</b>	
Kato	Diesel	GE	U30C	Kato		1161 (001 41 030) (MTL pilot: front & rear; 9 colors)		

Manufacturer	Locomotive/Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement
Kato	Diesel	GE	U-25B	Kato		1160 (001 32 080) (MTL pilot: front & rear)		
Kato	Diesel	GE	C30-7	Kato		1015 (001 02 000)		
<b>Kato</b>	<b>Diesel</b>	<b>GE</b>	<b>AC-4400 and CW version</b>	<b>Kato</b>		<b>2003, 1015</b>		
Kato	Diesel	GE	C44-9W	Kato		2001 (001 02 050), 2004 (001 050)	OEM Pilot: front and rear	
<b>kato</b>			<b>Genesis P42</b>	<b>Kato</b>		<b>2004 (001 02 052)-1</b>	<b>Remove Draft Gear, center coupler and fix in place with the clip that held the factory coupler</b>	
			<b>GG1</b>	<b>Kato</b>		<b>1023</b>	<b>Some clean up of the Pilot will be necessary.</b>	
			<b>EMD F40 PH</b>	<b>Kato</b>		<b>2004-1</b>		
Kato	Diesel		DD13 Switcher Center Cab	Kato	1128 (001 30 012), 1129 (001 30 013), 1130			
Kato	Diesel	(note)	Low Friction Blomberg Style Diesel Trucks	Kato	1128 (001 30 012), 1129 (001 30 013), 1130			
Kato	Electric		EF-15	Kato	1128 (001 30 012)			
Kato	Electric		EF-58	Kato	1128 (001 30 012)			
Kato	Electric		EF-57	Kato	1129 (001 30 013)			
Kato	Electric		EF-70	Kato	1129 (001 30 013)			
Kato	Electric		EF-81	Kato	1129 (001 30 013)			
Kato	Electric		EH-10	Kato	1129 (001 30 013)			
Kato	Electric		ED-79	Kato		2001 (001 02 050)		
			<b>Rolling Stock</b>					
Kato	Rolling Stock		Bethgon Coal Porter	Kato	1128 (001 30 012)			1030 (003)
Kato	Rolling Stock		Maxi Stack	Kato	1128			
Kato	Rolling Stock		ACF 70 ton 2 Bay Covered Hopper	Kato	1128 (001 30 012), 1129 (001 30 013), 1130		This car uses a snap on split bolster which makes it impossible to use MTL trucks with it.	
Kato	Rolling Stock		4 truck depressed center flat car	Kato	1049 (001 30 003)			
			Caboose, Shorty	Kato		2001 (001 02 050)	Remove Draft Gear Box and attach body mount couper	
Kato	Rolling Stock		Caboose (2000 Release)	Kato		1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)	Trim off the support lip from the draft gear box so that it doesn't interfere with the draft gear box adapter. Apply a small amount of glue to keep the draft gear box adapter from sliding too far back.	
<b>Kato</b>	<b>Passenger Car</b>		<b>Superliners</b>	<b>Kato</b>	<b>1129 (001 30 013) or 1130 (001 30 014)</b>			
Kato	Passenger Car		Corregated Passenger Car	Kato	1129 (001 30 013)			





Manufacturer	Locomotive/Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement	