

Manufacturer	Locomotive/Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement	Made In
Hallmark Models	Steam		2-10-4			1015 (001 02 000)/1016 (001 02 006) Pilot, 1023 (001 02 009)/1025 tender			
Hallmark Models	Steam		4-8-4			1015 (001 02 000)/1016 (001 02 006) Pilot, 1023 (001 02 009)/1025 tender			
Hallmark Models	Steam		2-8-2			1023 (001 02 009)/1025 tender only			
Hallmark Models	Steam		2-10-2			1023 (001 02 009)/1025 tender only			
Hallmark Models	Steam		4-6-2			1023 (001 02 009)/1025 tender only			
Hallmark Models	Steam		4-8-2			1023 (001 02 009)/1025 tender only			
Hallmark Models	Diesel	BLW	VO-1000 (003 01 021)			1023 (001 02 009)/1025			
Hallmark Models	Diesel		SD-45-2			1016 (001 02 006)	Cannot take 1015 (001 02 000)		Korea
Hallmark Models	Diesel		SD-45-2B Cabless Booster			1016 (001 02 006)	Cannot take 1015 (001 02 000)		Korea
Hallmark Models	Diesel		DL-109	SAM		1023 (001 02 009)/1025			
Hallmark Models	Diesel		RS-1	KMT		1023 (001 02 009)/1025			
Hallmark Models	Diesel		RS-2	KMT		1023 (001 02 009)/1025			
Hallmark Models	Diesel	Alco	RSC-2 locomotive			2001 (001 02 050)			
Hallmark Models	Diesel		RS-3	KMT		1023 (001 02 009)/1025			
Hallmark Models	Diesel		RSD-4/5	KMT		1023 (001 02 009)/1025			
Hallmark Models	Diesel		Centipede	KMT		1023 (001 02 009)/1025			
Hallmark Models	Diesel	BLW	DS-4-4-6			1023 (001 02 009)/1025			
Hallmark Models	Diesel		DS-4-4-10	SAM		1023 (001 02 009)/1025			
Hallmark Models	Diesel		S-12	SAM		1023 (001 02 009)/1025			
Hallmark Models	Diesel	EMD	E-3/6 A&B	KMT		1023 (001 02 009)/1025			
Hallmark Models	Diesel	EMD	E-5 A&B	KMT		1023 (001 02 009)/1025			
Hallmark Models	Diesel	EMD	FT A&B	SAM		1023 (001 02 009)/1025			
Hallmark Models	Diesel	EMD	F-3 A&B	SAM		1023 (001 02 009)/1025			
Hallmark Models	Diesel	EMD	F-7 A&B	SAM		1023 (001 02 009)/1025			
Hallmark Models	Diesel	EMD	F-7 A&B			1015 (001 02 000)	INSTRUCTIONS: (1) Add a .010" shim between coupler and loco mounting pad. (2) Remove .005" off each side of the pilot opening and .020" off the bottom edge of pilot opening		
Hallmark Models	Diesel	EMD	F-9 A&B	SAM		1023 (001 02 009)/1025			
Hallmark Models	Diesel	EMD	GP-7	SAM		1023 (001 02 009)/1025			
Hallmark Models	Diesel	EMD	GP-9	SAM		1023 (001 02 009)/1025			
Hallmark Models	Diesel	EMD	GP-18	SAM		1023 (001 02 009)/1025			
Hallmark Models	Diesel	EMD	GP-20	SAM		1023 (001 02 009)/1025			

Manufacturer	Locomotive/Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement	Made In
Hallmark Models	Diesel	EMD	SD-45-T2	SAM		1016 (001 02 006) Front, 1015 (001 02 000) Rear			
Hallmark Models	Diesel	EMD	SD-50	SAM		1016 (001 02 006) Front, 1015 (001 02 000) Rear			
Hallmark Models	Diesel	EMD	SD-60	SAM		1016 (001 02 006) Front, 1015 (001 02 000) Rear			
Hallmark Models	Diesel		8-39W			1023 (001 02 009)/1025			
Hallmark Models	Diesel		8-40BW			1023 (001 02 009)/1025			
Hallmark Models	Diesel		8-40CW			1023 (001 02 009)/1025			
Hallmark Models	Diesel		U23-B	SAM		1021 (001 02 021), 1023 (001 02 009)/1025			
Hallmark Models	Diesel		U23-C	SAM		1021 (001 02 021)			
Hallmark Models	Diesel		U30-C	SAM		1021 (001 02 021)			
Hallmark Models	Diesel		U30-B	SAM		1021 (001 02 021), 1023 (001 02 009)/1025			
Hallmark Models	Diesel		U33-B	SAM		1021 (001 02 021), 1023 (001 02 009)/1025			
Hallmark Models	Diesel		U33-C	SAM		1021 (001 02 021), 1023 (001 02 009)/1025			
Hallmark Models	Diesel		U36-B	SAM		1021 (001 02 021)			
Hallmark Models	Diesel		U36-C	SAM		1021 (001 02 021), 1023 (001 02 009)/1025			
Hallmark Models	Diesel		U50-B	SAM		1023 (001 02 009)/1025			
Hallmark Models	Electric		M-190 Gas-Electric	SAM		1023 (001 02 009)/1025			
Hallmark Models	Rolling Stock		ATSF High Level	KMT		1023 (001 02 009)/1025			
Hallmark Models	Rolling Stock		UP Caboose			1023 (001 02 009)/1025			
Key Imports	Steam		2-8-2			1015 (001 02 000)/1016 (001 02 006) Tender only			
Key Imports	Steam		2-6-6-6			1023 (001 02 009)/1025 Pilot & Tender			
Key Imports	Steam		4-8-4			1023 (001 02 009)/1025 Tender only			
Key Imports	Steam		2-8-4 Berkshire S1 Class			1023 (001 02 009)/1025 Tender only			
Key Imports	Steam		SD-AC-12 Cab Forward			2001 (001 02 050) with shim, tender only	Requires approximately .035" shim		
Key Imports	Diesel		SD40		1015 (001 02 000)/1016 (001 02 006), 1023 (001 02 009)/1025				Japan
Key Imports	Diesel		SD40-2		1015 (001 02 000)/1016 (001 02 006)		Remove the body shell by unscrewing the gas tank from the underbelly. Press the pins out that are holding the trucks on. Unscrew the pilot from the truck. Unscrew, remove and discard the Rapido coupler and gear box. Insert the 1015 (001 02 000)/1016 (001 02 006) gear box into the pilot opening and screw it into place using the 00-90 screw		Japan

Manufacturer	Locomotive/Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement	Made In
Overland Models	Diesel		DD-40AX			1023 (001 02 009)/1025			
Overland Models	Diesel		Amtrack B32-8P-DM Locomotive			1023 (001 02 009)/1025			
Pecos River Brass			Most Models			1023 (001 02 009). 1025			
Sunset Models	Electric		DD-1			1021 (001 02 021)	INSTRUCTIONS: (1) After the coupler is assembled and heat sealed, enlarge the mounting hole with a #52 Drill (.052 diameter) to fit the metric screw. (2) Carefully file the pin on top of lid flush (see Fig. 1A) in #1021 (001 02 021)/1022 instructions. (3) File the width of the draft gear box a few thousandths of an inch to fit the slightly narrower draft gear pocket. The alternative to this is to file wider the draft gear pocket of the model, you have a choice. (4) Insert the coupler assembly into the loco draft gear pocket, reinstall the screw. (5) Follow testing procedures in		