

Manufacturer	Locomotive/ Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement	Made In
Minitrix	Steam		0-6-0T Donkey	Minitrix		1105			Germany
Minitrix	Steam		0-6-0 Switcher (w/ Old Time Tender)	Minitrix		Tender: 1104 (001 30 009) (001 30 009)			Germany
Minitrix	Steam		0-6-0 Switcher (w/ Slope Back Tender)	Minitrix		1104 (001 30 009) (001 30 009)			Germany
Minitrix	Steam		2-10-0 Decapod: pilot	Minitrix	Pilot: 1130 (001 30 014) (remove cowcatcher); Tender: 1128 (001 30 012), 1129 (001 30 013)	MTL pilot: 1043 (001 30 010) (requires modification -- NOT RECOMMENDED FOR NOVICE)			Germany
Minitrix	Steam		4-6-2 K4 Pacific (w/ 4-wheel tender truck)	Minitrix	Tender: 1128 (001 30 012), 1129 (001 30 013)	1043 (001 30 010) (MTL pilot and tender truck replacement. Pilot requires modification -- NOT RECOMMENDED FOR NOVICE)			Germany
Minitrix	Diesel	EMD	F-9A	Minitrix	1103 (001 44 000)				Germany
Minitrix	Diesel	EMD	F-9B	Minitrix	1125, 1129 (001 30 013)				Germany
Minitrix	Diesel	FM	H-12-44 Switcher	Minitrix	1049 (001 30 003), 1104 (001 30 009) (001 30 009), 1128 (001 30 012)				Germany
Minitrix	Diesel	GE	U28	Minitrix	1049 (001 30 003), 1104 (001 30 009) (001 30 009), 1129 (001 30 013)				Germany
Minitrix	Diesel	GE	U30CG	Minitrix	1049 (001 30 003), 1104 (001 30 009) (001 30 009), 1129 (001 30 013)				Germany
Minitrix	Diesel	Plymouth	MDT Industrial Switcher	Minitrix	1128 (001 30 012)				Austria
Minitrix			Truck Mount Cars	Minitrix	1128 (001 30 012)				
Minitrix	Cars		Passenger or Freight Cars, body mount				1015, see instructions for clarification.		
MDC/ Roundhouse	Steam		2-6-0 Steam	MDC	1129 (001 30 013)				

Manufacturer	Locomotive/ Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement	Made In
MDC/ Roundhouse	Steam		2-8-0 Steam	MDC	1129 (001 30 013)				
MDC/Round House	Rolling Stock		High Side Thrall Gondola			1016 (001 02 006) (lid up)	Use 00-90 screw w/ countersink head, & trim end flush w/ inside frame so weight fits properly (no coupler fits MDC draft gear box)	1037 (003 01 042)	
MDC/Round House	Rolling Stock		50' Overland Passenger Car		1112 (001 32 020)				
MDC/Round House	Rolling Stock		50' Express Reefer			1015 (001 02 000), 1016 (001 02 006)	Due to the way the truck mounted draft gear box is made on the commonwealth freight trucks on this model, truck conversions are not possible. Remove the gear box. Drill and tap an 00-90 hole 1/16 in from the end of the underbody. (Note: the coupler must be mounted 1/16 in, not 1/8 in from the end, or else the draft gear box will interfere with the trucks.) The coupler will need a .038" shim in order to set it at the proper height (.216"). Note: Using 3/16" 00-90 screws requires an additional 1/16" hole in the bottom of the car shell at		U.S.A.
MDC/Round house	Rolling Stock		Husky Stack	Model Die Casting			Remove a portion of end sill for draft gear box clearance	1037 (003 01 042)	China

Manufacturer	Locomotive/ Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement	Made In
MDC/Round house	Rolling Stock		70-Ton 3-Bay Open Hopper	Model Die Casting		1023 (001 02 009)/1025	Instructions: Body Mount: (1) File off .020" (0.5 mm) from underside of mounting pad on diecast underframe. (2) Drull out coupler mounting screw hole using #56 drill and tap for 00-90 screw. (3) Trim off about .050" (1.25 mm) from rear of assembled #1023 (001 02 009)/1025 draft gear box so it is even with the ends of the coupler shanks. (4) File the rounded outward facing part of body bolster flat just enough to fit into the mounting pad. (5) Trim the truck bolster on one side so that it doesn't rub the draft gear box. MTL Truck Replacement: File off .025" (0.65 mm) from underside of coupler mounting pad on	1000 (003 01 021)- 1 (low profile wheels)	
MDC/R.H.	Rolling Stock		50' PS1 Box Car			1128 (001 30 012)		1000 (003 01 021)- 1	
MDC/Round house	Rolling Stock		30' modern tank	MDC		1015 (001 02 000)	Body Mount:trim off anti-sway pins on body bolster	1037 (003 01 042)	
MDC/Round house	Rolling Stock		36' steel underframe reefer	MDC		1015 (001 02 000)/1016 (001 02 006)	Body Mount:notch the center of end sill .150" wide by .028" high to match coupler mounting pad. Drill out screw hole, tap for 00-90. MTL Truck Replacement: trim [raise] entire width of end sill by .020" to clear top of draft gear	1000 (003 01 021)	
MDC/Round house	Passenger Car		Overton Coach	Model Die Casting		1015 (001 02 000)/1016 (001 02 006)		1003 (003 01 022) with washer	
MDC/Round house	Cars		Freight Cars (w/ split 1 pc. draft gear box)	Model Die Casting	1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)				U.S.A.
MDC/Round house	Cars		Freight Cars (w/ metal draft gear box clip- long)	Model Die Casting	1128 (001 30 012)				U.S.A.
MDC/Round house	Cars		Freight Cars (w/ metal draft gear box clip-short)	Model Die Casting	1129 (001 30 013)				U.S.A.

Manufacturer	Locomotive/ Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement	Made In
MDC/Round house	Cars		Freight truck (w/ mounted MTL coupler assy)					1000 (003 01 021), 1002 (003 01 024), 1003 (003 01 022), 1010 (001 30 004) (003 01 001), 1030 (003 01 031), 1012 (003 01 004), 1030 (003 01 031), 1032 (003 01 034), 1035 (003 01 041), 1037 (003 01 042),	
Mehano	Diesel		F-7		1104 (001 30 009) (001 30 009)		For Truck mounted conversion: Trim spring retaining post to allow 1104 (001 30 009) (001 30 009) adaptor to easily slide in and out of the draft gear box		
Mehano	Diesel		Dash 7		1104 (001 30 009) (001 30 009)		For Truck mounted conversion: Trim spring retaining post to allow 1104 (001 30 009) (001 30 009) adaptor to easily slide in and out of the draft gear box		