

Manufacturer	Locomotive/ Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement	Made In
Model Power	Steam		0-6-0 Side Tank Switcher	Model Power		1113 (001 30 005)			Yugoslavia
Model Power	Steam		0-6-0T Donkey	Minitrix		1105			Germany
Model Power	Steam		0-6-0 Switcher (w/ Old Time Tender)	Minitrix		1104 (001 30 009) (001 30 009)			Germany
Model Power	Steam		0-6-0 Switcher (w/ Slope Back Tender)	Minitrix		1104 (001 30 009) (001 30 009)			Germany
Model Power	Steam		USRA 2-8-2 Mikado	MP	1023 (001 02 009)		Remove coupler, trim wings off lower portion of coupler platform, add .010 shim under coupler and attach with 00-90 screw.		
Model Power	Steam		ASE 4-4-0	MP		1025			
Model Power	Steam		USRA 2-8-2 Mikado W/Vanderbilt Tender	MP		1025			
Model Power	Steam		Pacific 4 6 2		no conversion	1025			
Model Power	Steam		2-6-0 Mogul with Vandy Tender			1025			
Model Power	Steam		Pacific 4 6 2 with Vanderbilt Tender			1025			
Model Power	Steam		2-10-0 Decapod: pilot	Minitrix	Pilot: 1130 (001 30 014) (remove cowcatcher); Tender: 1128 (001 30 012), 1129 (001 30 013)	MTL pilot: 1043 (001 30 010) (requires modification -- NOT RECOMMENDED FOR NOVICE)			Germany
Model Power	Steam		4-6-2 Pacific: pilot	Minitrix	Pilot: 1130 (001 30 014) (remove cowcatcher); Tender: 1128 (001 30 012)	MTL pilot: 1043 (001 30 010) (requires modification -- NOT RECOMMENDED FOR NOVICE)	1130 (001 30 014) (remove cowcatcher)		Germany
Model Power	Diesel	Alco	Century 420 (formerly MRC)	Model Power	1049 (001 30 003), 1104 (001 30 009) (001 30 009), 1110				Yugoslavia
Model Power	Diesel	Alco	FA-2	Model Power	1110, 1109 (001 30 008)				Yugoslavia
Model Power	Diesel	EMD	F9 A	Minitrix	1103 (001 44 000)				Germany
Model Power	Diesel	EMD	F9 B	Minitrix	1125, 1129 (001 30 013)				Germany
Model Power	Diesel	EMD	F40 PH	Model Power	1049 (001 30 003), 1110				Yugoslavia

Manufacturer	Locomotive/ Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement	Made In
Model Power	Diesel		FP-7	Model Power		1129 or 1016	1129 straight across conversion, 1016 for the pilot requires .020" shim and some thick super glue in the hole to fit the 00-90 screws		
Model Power	Diesel	EMD	GP-38-2	Model Power	1128 (001 30 012)				China
Model Power	Diesel	EMD	GP-40	Model Power	1049 (001 30 003), 1104 (001 30 009) (001 30 009)				Yugoslavia
Model Power	Diesel	FM	H 12-44 Switcher	Minitrix	1049 (001 30 003), 1128 (001 30 012)				Germany
Model Power	Diesel	Alco	RSD-15 (formerly MRC) #7549	Mehano	1110, 1049 (001 30 003), 1104 (001 30 009) (001 30 009)				Yugoslavia
Model Power	Diesel	Alco	RSD-45	Model Power	1049 (001 30 003), 1104 (001 30 009) (001 30 009)				Yugoslavia
Model Power	Diesel	EMD	SD-45	Model Power	1109 (001 30 008), 1128 (001 30 012)				Yugoslavia
Model Power	Diesel		Century 420		1049 (001 30 003)				Yugoslavia
Model Power	Rolling Stock		Hopper 4-bay #3471		1128 (001 30 012)				Yugoslavia
Model Power	Rolling Stock		Tank Car #3417		1128 (001 30 012)				Hong Kong
Model Power	Rolling Stock		40' Box Car (w/ split 1 pc. draft gear box)		1128 (001 30 012)				Yugoslavia
Model Power	Passenger Car		Heavyweight Passenger Cars (series #8627)	Lima	1129 (001 30 013), 1130 (001 30 014)				Italy
Model Power	Cars		Passenger or Freight Cars (w/ split 1 pc. draft gear box)		1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)				
Model Power	Cars		Passenger or Freight Cars (w/ metal draft gear box clip )		1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)				

Manufacturer	Locomotive/ Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement	Made In
Model Power	Cars		Freight truck (w/ mounted MTL coupler assy)					1000 (003 01 021), 1002 (003 01 024), 1003 (003 01 022), 1010 (001 30 004) (003 01 001), 1030 (003 01 031), 1012 (003 01 004), 1030 (003 01 031), 1032 (003 01 034), 1035 (003 01 041), 1037 (003 01 042),	
Model Power	Cars		Passenger truck (w/ mounted MTL coupler assy)					1017 (003 41 051), 1018 (003 41 061)	
Model Power	Cars		Passenger or Freight Cars, body mount				body mount (refer to the body mount applications section in the conversion guide for instructions)		



Manufacturer	Locomotive/ Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement	Made In