


HOW TO

TURN ON/OFF LED LIGHTED MICRO-MOUSE CHRISTMAS CAR




ITEM# 102 00 820 REL. 10/2019

TO TURN ON:
TOUCH MAGNET END OF MAGNETIC
WAND OVER NON-BRAKE WHEEL END
OF CAR NEAR GRAB IRONS



TO TURN OFF:
APPROACH SAME SPOT AS BEFORE AND
TOUCH MAGNET END OF MAGNETIC
WAND ONCE MORE



WWW.MICRO-TRAINS.COM